



VIRTUAL POLYMER
COMPOUNDS, LLC

10478 Ridge Road | Medina, New York 14103
Phone: 585-735-9668 | Toll Free: 888-290-9522 | Fax: 585-735-9965
www.vpcfiberglass.com

**(SUGGESTED)
INSTALLATION INSTRUCTIONS**

Installation of the unit is performed by the use of wedge, sleeve, stud, or high performance epoxy drop-in anchors a minimum 3/8" diameter 4" length is recommended. **(Installation materials are to be supplied by the user.)** It is suggested that the user adhere to the following procedure for proper installation:

STEP 1. Locate the unit in its desired position on a concrete pad with a minimum thickness of 4". **UNIT MUST BE LEVELED TO ASSURE LEAK RESISTANCE AND PROPER OPERATION OF DOOR.**

STEP 2. Remove interior baseboard molding.

STEP 3. Drill mounting holes within center of mounting flange with center locations approximately 6" on each side of the column covers. Apply anchors.

STEP 4. Reinstall baseboard molding.

STEP 5. Seal exterior perimeter of unit at base with a good-quality construction sealant per detail below.

NOTE: IN ADDITION TO ABOVE INSTRUCTIONS, ANY ADDITIONAL REQUIREMENTS IMPOSED BY APPLICABLE STATE AND LOCAL BUILDING CODES MUST BE FOLLOWED. CHECK WITH LOCAL AUTHORITIES IF NECESSARY.

